

0.04 trace =3A at 30C overtemp.

Minimum trace separation at 500V is 1.8mm

But we have solder mask and professionally

manufactured boards, and max 400V we don't need 1.8mm.

Investigate protective paint. Min drill dia=16mil

